



PO Box 8423, Orange NSW 2800. P: (02) 6361 1633. F: (02) 6361 1644. E: office@westinspect.net.au  
Building Consultancy Lic No: 2083. Builders Lic No 7516C. ABN: 42 721 890 557

## ***Method of Shower Repair*** ***Waterproofing Conforms to AS 3740.***



1. Remove existing wall tiles



3. Repair or replace broken wall sheeting if required



2. Removal of wall tiles and remove floor tiles



4. Repair or replace broken wall sheeting if required



5. Remove broken wall sheeting and replace with new.

NOTE: normally only one row of wall tiles is removed, however in this case due to broken wall sheeting more than one row had to be removed.



6. New wall sheeting installed, new mortar bed also installed



7. Waterproofing to AS 3740 installed.



8. New wall tiles and floor tiles installed prior to grouting.



9. Floor and wall tiles grouted prior to cleaning.

NOTE: it is not always possible to obtain tiles that are a perfect match to the existing.

10. Reinstall shower screen.